

FIELD ASSEMBLY

REFER TO DRAWING

OPTION 2

FOR 3/16" Ø CABLE

1. CUT EXCESS THREAD
2. SCREW ON STAINLESS
COVER

THROUGH POST

USE 1/4" Ø DRILL FOR 1/8" Ø CABLE USE 9/64" Ø DRILL

STAINLESS CABLE

QUICK NUT

FOR 3/16" 01-009-01

FOR 1/8" 01-031-01

NOTE: USE ALUMINUM, STAINLESS STEEL OR WOOD POST

Copyright © 2011 Stainless Cable & Railing.
All rights reserved.

Scaling
Cable &
Cable